



## Fix Your Cracks — “Do it the RiteWay”

To ensure that you are getting the best crack repair system, include the following bid specifications:

1. Clean out crack making it free of dirt and other debris.
2. Crack to be filled from bottom to top with court patch binder or cement and let dry.
3. Filled crack must be scraped or buffed flush with court and cleaned, broomed and blown.
4. Area to be repaired must be DRY and at 60°F and up to 100°F.
5. Apply RiteWay Crack Repair System, centering the first layer RiteWay MicroSealant™ tape over filled crack. This flexible adhesive layer is key to the system. “Slip sheet” systems are not equivalent.
6. Apply Liquid Acrylic and Latex binding formula (50/50) over MicroSealant™ tape. Apply second layer 20” stress mat centered over first layer saturating with binding formula.
7. Apply binding edge, the third layer of the RiteWay Crack Repair System, centered over stress mat edge. Let dry.
8. When dry, apply a minimum of two coats of acrylic resurfacer with sand lengthwise over crack repair.
9. The courts are ready to be color coated and striped.

www.RiteWayTennis.com

**No Dead Spots • No Hollow Sounds • No Bubbling**

Fix your problem cracked courts.

**“Do it the *RiteWay*.”**



RiteWay Tennis Products • 4 Sycamore Way • Branford, CT 06405 • 1-877-5-RiteWay